

GasProbe CO

Carbon Monoxide Meter

"INNOVATORS IN GAS DETECTION"

BW
Technologies



**One-button
operation**



Measure CO Levels

- △ LCD displays CO levels from 0-1,000 ppm
- △ The higher the concentration of CO, the faster the beeper sounds
- △ LCD backlight activates automatically in lowlight conditions
- △ Automatic sensor zeroing and self-test sequence upon startup
- △ Stores and displays the maximum CO levels encountered (MAXHOLD)
- △ CO level beeper can be silenced if desired
- △ Automatic power-off after 20 minutes extends battery life
- △ Simple, automatic calibration procedure
- △ Easy-to-replace 9 VDC battery (battery life 500 hours)
- △ Stabilized electrochemical CO specific sensor
- △ Typical three year sensor life, one year calibration cycle
- △ Manuals available in local languages
- △ One year warranty including sensors



SamplerPak

Ordering Information

CO-PROBE Handheld Carbon Monoxide Meter

Accessories and Spares

CO-CASE1	Carrying Case
CO-AK1	Manual Aspirator Kit
SR-M2FL	Carbon Monoxide (CO) Sensor
GA-WS2	Wrist strap
GA-SPAK	SamplerPak (North American approvals)
GA-SPAK02	SamplerPak (European approvals)

SamplerPaks complete with: the Sampler motorized sampling pump, two rigid sample tubes with barbed fitting (small: 4.65 in. / 11.8 cm; medium: 10.25 in. / 26 cm), flexible sampling hose (10 ft. / 3 m) with airstone water/particulate filter, connector hose (3 ft. / 0.9 m), two AA alkaline batteries, two extra particulate filters, instructions and a hard-sided, foam-lined carrying case.

GasProbe CO

Carbon Monoxide Meter

Compact and lightweight, the GasProbe CO provides fast, accurate sampling of CO concentrations from 0 to 1,000 parts per million (ppm).

GasProbe CO is ideal for technicians, fire department personnel and other professionals who need to measure CO levels where accumulation of combustion gas is possible, such as industrial environments, commercial buildings, or residential dwellings.

Additional Features:

LCD Display: Large, continuous, alphanumeric display advises in ppm

Audible Indicator:

The beeper functions much like the clicking of a Geiger counter:

The higher the concentration of CO, the faster the beeper sounds.

Above 200 ppm, the beeper sounds continuously. The frequency of the tone increases with the concentration of CO.

"INNOVATORS IN GAS DETECTION"



For further information:

1-888-749-8878 USA
1-800-663-4164 Canada
+44 (0) 1869 233004 Europe
+971-4-8871766 Middle East
+61-7-3818-8244 Australia
+852-2974-1783 China
+1-403-248-9226 Other Countries

Corporate Headquarters

2840 - 2 Avenue S.E.
Calgary, AB, Canada T2A 7X9
Phone: +1-403-248-9226
Fax: +1-403-273-370

SPECIFICATIONS

Operating Temperature:	GasProbe CO Carbon Monoxide Meter
Operating Humidity:	32 to 122 °F / 0 to 50 °C
Gas Sensors:	0% to 99% RH (non-condensing)
Measuring Range:	Electrochemical (carbon monoxide)
	0-1,000 ppm
Indicators:	Beeper tone and ppm readout
BATTERY:	Standard 9-volt
Battery life:	500 hours typical
DISPLAY:	Status-at-a-glance alphanumeric LCD
Backlight:	Automatically turns on in low light conditions
Records/Displays:	Maximum CO exposure encountered on demand
SELF-TESTS:	On activation (auto): verifies sensor integrity and battery
	Continuous: battery operation is continuously monitored
PHYSICAL:	Shock resistant ABS enclosure
Size:	1.75 x 2.0 x 7.0 inches / 45 x 50 x 180 mm
Weight:	5.2 oz. / 147 g including battery
WARRANTY:	1 year including sensors (typical sensor life 3 years)

DUE TO ONGOING RESEARCH AND PRODUCT IMPROVEMENT, SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.



- 1 LARGE, HIGH-CONTRAST LCD
- 2 AUTO BACKLIGHT IN LOW LIGHT CONDITIONS
- 3 SIMPLE CONTROLS
- 4 ADVANCED MICROCONTROLLER BASED OPERATION
- 5 9 VDC BATTERY
- 6 COMPACT AND LIGHTWEIGHT

Accessories Available



Sampler Motorized sampling pump

Locally distributed by: www.geass.com - Torino (Italy) - info@geass.com