

Wood Moisture Meter

Integral pins and Remote hand-press probe

Monitor moisture in wood either directly with the built-in moisture pins or use remote hand-press probe on hard surfaces. Designed in a rugged double molded housing construction and is pocket sized for one-handed operation

Features:

- Memory contains 8 wood groups with calibrations for approximately 170 species of wood
- Measurements can be taken using the integral pin electrodes (replaceable pins) or a heavy duty remote probe (included)
- Automatically temperature compensated (ATC) readings when used with the temperature probe (included)
- Built-in calibration check
- User settable Auto power off (1 to 9 minutes) with disable
- Low battery indication
- Complete with remote hand-press moisture probe, Temperature probe, protective cap, replacement pins, pouch case, and two AAA batteries



Measure moisture directly on the material or use remote hand-press moisture probe (included) on hard materials. Also includes a temperature probe to measure Temperature and adds automatic Temperature Compensation (ATC) to your Moisture measurements for better accuracy.

Distributore Autorizzato : Geass S.r.l. - Torino - Tel.: +39 011.22.91.578 - info@geass.com - web site :www.geass.com

Ordering Information:

M0220.....Wood Moisture Meter

M0220-PINS ..Replacement Moisture pins for M0220 (50pins)

