





## PR 6011

## Mounting kits for load cell PR 6211




- Simple and fast installation
- Proven mounting kits for vessels
- Highest weighing performance due to special adaption of load cell and mounting kit
- Optional with built-in dummy function
- Prepared for the installation of a lift-off-protection
- Full stainless steel version available
- Inclusive constrainer
- Maintenance free
- Compact design



The standard version is available in zinc plated and chromated steel. For the chemical and food industries with their high requirements to durability and hygiene. The MiniFlexlock is also available in stainless steel. The built-in constrainer absorbs horizontal forces, while leaving the object free to expand in case of temperature changes. The mounting kits are 100 % maintenance free.


# Mounting plate kit and MiniFLEXLOCK for PR 6211 (500 kg... 10 t)

PR 6011/10N&S



Dimensions in mm

MiniFLEXLOCK PR 6011/30N&S



Dimensions in mm

## PR 6011/10

### Technical data

Mounting with bolts M10

### Version

- N-Version: mild steel, zinc plated, chromated
- S-Version: stainless steel 1.4301 according to DIN EN 10088-3

## MiniFLEXLOCK PR 6011/30

### Technical data

Mounting with bolts M8

Max. continuous horizontal force for the constrainer 5 kN

Destructive force of the constrainer > 10 kN

### Version

- N-Version: mild steel, zinc plated, chromated
- S-Version: stainless steel 1.4301 according to DIN EN 10088-3 (all parts including the swivel bearings are made of stainless steel)

### Accessories

(supplied with the mounting kits)


- Bolts and washer to fix the earthing cable
- Instruction manual
- Drilling template

## Order information

Type	Description	Packing	Weight gross   net	Order number
PR 6011/10N	Mounting plate kit	27 × 16 × 3 cm	2.4 kg   2.3 kg	9405 360 11101
PR 6011/10S	Mounting plate kit, stainless steel	27 × 16 × 3 cm	2.4 kg   2.3 kg	9405 960 11112
PR 6011/30N	MiniFLEXLOCK, 5 kN	22 × 16 × 12 cm	5.5 kg   5.1 kg	9405 360 11301
PR 6011/30S	MiniFLEXLOCK, 5 kN, stainless steel	22 × 16 × 12 cm	5.5 kg   5.1 kg	9405 960 11402


# Mounting plate kit and SeismoFLEX for PR 6211 (500 kg... 10 t)

PR 6011/11N&S



Dimensions in mm

PR 6011/40N&S



Dimensions in mm

## PR 6011/11

### Technical data

Mounting with bolts M12

### Version

- N-Version: mild steel, zinc plated, chromated
- S-Version: stainless steel 1.4301 according to DIN EN 10088-3

## MiniFLEXLOCK PR 6011/40

### Technical data

Mounting with bolts M12

Max. continuous horizontal force for the constrainer 20 kN

Destructive force of the constrainer > 50 kN

### Version

- N-Version: mild steel, zinc plated, chromated
- S-Version: stainless steel 1.4301 according to DIN EN 10088-3 (all parts including the swivel bearings are made of stainless steel)

## Accessories

(supplied with the mounting kits)


- Bolts and washer to fix the earthing cable
- Instruction manual
- Drilling template

## Order information


Type	Description	Packing	Weight gross   net	Order number
PR 6011/11N	Mounting plate kit	18 × 15 × 18 cm	6.9 kg   6.5 kg	9405 360 11111
PR 6011/11S	Mounting plate kit, stainless steel	18 × 15 × 18 cm	6.9 kg   6.5 kg	9405 960 11112
PR 6011/40N	MiniFLEXLOCK, 20 kN	24 × 19 × 18 cm	8.58 kg   8.13 kg	9405 360 11401
PR 6011/40S	MiniFLEXLOCK, 20 kN, stainless steel	30 × 16 × 17 cm	8.40 kg   8.15 kg	9405 960 11402

## Mounting kits for PR 6211 (30 kg... 300 kg)

Rubber Mounting Kit PR 6011/03





Mounting Plate Kit PR 6011/00



\*\* M6 thread in lower plate for lift-off protection

PR 6011/20



Dimensions in mm

Dimensions in mm

### Rubber mounting kit PR 6011/03N

Suitable for PR 6211 with capacities from 30 kg up to 300 kg

### Max. vertical load

450 kg

### Operating temperature

-45 °C... +70 °C (-49 °F... +158 °F)

### PR 6011/00

#### Technical data

Mounting with bolts M6

#### Version

- N-Version: mild steel, zinc plated, chromated
- S-Version: stainless steel 1.4301 according to DIN EN 10088-3

### MiniFLEXLOCK PR 6011/20

#### Technical data

Mounting with bolts M6

Max. continuous horizontal force of the constrainer 450 N

#### Version

- N-Version: mild steel, zinc plated, chromated
- S-Version: stainless steel 1.4301 according to DIN EN 10088-3 (all parts including the swivel bearings are made of stainless steel)

#### Accessories

(supplied with the mounting kits)

- Bolts and washer to fix the earthing cable
- Instruction manual
- Drilling template

### Order information

Type	Description	Packing	Weight gross   net	Order number
PR 6011/00N	Mounting plate kit	22 × 15 × 4 cm	0.5 kg   0.4 kg	9405 360 11001
PR 6011/00S	Mounting plate kit, Stainless steel	22 × 15 × 4 cm	0.5 kg   0.4 kg	9405 960 11002
PR 6011/03N	Elastomerlager	-	0.34 kg   0.3 kg	9405 360 11031
PR 6011/20N	MiniFLEXLOCK, 450 N	22 × 15 × 4 cm	0.6 kg   0.5 kg	9405 360 11201
PR 6011/20S	MiniFLEXLOCK, Stainless steel, 450 N	22 × 15 × 4 cm	0.6 kg   0.5 kg	9405 960 11202

The technical data specified above only serve to describe the product and should not be construed as warranted characteristics in the legal sense.

Specifications subject to change without notice  
 Printed in Germany | W  
 Publication No.: HPR2037-e14092  
 Order No.: 9498 760 11001  
 Version 09.2014

Sartorius Mechatronics T&H GmbH  
 Meiendorfer Straße 205  
 22145 Hamburg, Germany