# Low Viscosity Adapters







## LOW VISCOSITY ADAPTER WITH FLOW JACKET

Low Viscosity adapter is used with the rotational viscometers to perform accurate and reproducible measurements on low viscosity materials, from 1 cP (mPa·s), as well as shear rate and shear stress determinations. It is supplied with spindle.

#### Technical features

- Sample volume: from 16 to 18 ml.
- Flow jacket that allows thermostatisation of the sample from -10 to +100°C.
- Removable stainless steel sample container easily cleaned.
- PT100 probe to determine the sample temperature with accuracy (optional).





### LOW VISCOSITY ADAPTER WITHOUT FLOW JACKET

Low Viscosity adapter is used with the rotational viscometers to perform accurate and reproducible measurements on low viscosity materials, from 1 cP (mPa·s), as well as shear rate and shear stress determinations. It is supplied with spindle.

#### Technical features

- Sample volume: from 16 to 18 ml.
- Removable stainless steel sample container easily cleaned.
- PT100 probe to determine the sample temperature with accuracy (optional).

Viscometer model	Viscosity range with LCP and LCP/B
L	1 - 2,000 cP
R	5 - 21,333 cP